

Order-No.: DD+DIS024.00E

**July 2000** 



# ADC System Components ID - Station

## **Installation Instructions**

Please file this document in section 3 of your Technical Documentation.

## **Fresh Installation:**

## **PRID 1.1.10**

# for the ID-Station

#### **List of Contents**

1	General Information	. 1
1.1	Software Prerequisites	. 1
1.2	Hardware Prerequisites	. 1
1.3	Required Time for the Installation	. 1
1.4	Contents of Delivery Software Kit PRID 1.1.10	. 1
1.5	Release Environment	. 2
_		
2	Installation of PRID 1.1.10	. 3
2 3	Installation of PRID 1.1.10 Further Steps for Start up	
	Further Steps for Start up	. 5
3		<b>. 5</b> . 5
<b>3</b> 3.1	Further Steps for Start up Install and select the Language File	. <b>5</b> . 5

#### 1 General Information



The "Fresh Installation" is only necessary if you do not purchase the hardware of the Preview- and ID-Station via AGFA.

If purchased via AGFA everything is installed and configured according to the order.

#### 1.1 Software Prerequisites

Preview- and ID-Station: WINDOWS 95/98 or WINDOWS NT installed.

Processing Station:  $\geq$  VIPS 1.0.05

ADC Compact DIGITIZER: ≥ COP\_1215 + patch COPA1215;

(Order No.: CM+9.5145.1050.2)

(Order No.: CM+9.5155.1050.2)

#### 1.2 Hardware Prerequisites

see section 14 of your Technical Documentation

### 1.3 Required Time for the Installation

Less than 15 minutes.

#### 1.4 Contents of Delivery Software Kit PRID 1.1.10

· consists of:

1 x CD ROM: PRID 1.1.10

1 x User Manual User Manual for PRID

1 x Floppy disk: Language files LNG.1.0.05 for PRID  $\geq$  1.1.05

#### 1.5 Release Environment

These versions on the hardcopy devices and the IMPAX Stations (and subsequent releases respectively) guarantee that all functions on the PRID Station are supported properly. Other combinations have not been tested and may result in restrictions in functionality.

LR5200	≥ LTP01901
LR5200 Controller	≥ AOS32946/C
	≥ CAD32946/C
	≥ ECU32947/C
DICOM	≥ DCM2.3.4/C
IMPAX	≥ R3.5_v.2.4.0/C

Connection to third party PACS-systems and printers is continuously enlarged.

Please follow the connectivity release notes to get the latest update.

## 2 Installation of PRID 1.1.10



- Make sure that the ID-tablet is connected to COM1 of the PC.
- If you are not sure, that the preset ip-address of your PC is used in the local network, disconnect it from the network.

#### **Installation Procedure**

No.	Procedure Steps	Display / Comment
1.	Switch on PC and ID-tablet	
2.	• Insert CD ROM with PRID 1.1.10. The	The following window appears:
	"Install Wizard" starts automatically. If not, eject and insert the CD ROM once again.	Welcome
3.	• Click <next>.</next>	The following window appears:
		User Information
4.	Fill in Name and Company and	The following window appears:
	click <next>.</next>	License registration
5.	Enter the license number for	The following window appears:
	the ADC Preview SW and/or ADC ID SW and click <next>.</next>	Choose Destination Location



Edit the license number written on the license card coming with PRID 1.1.10 for the ID-Station SW. The application will not run without that numbers.

6.	•	Select destination folder C:\prid and	The following window appears:
		click <next>.</next>	Start Copying Files
7.	•	Click <next>.</next>	Installation starts and the window PRID1Version 1.10 appears.
			Files are copied.
			Then the following window appears:
			Setup Complete
8.	•	Click <finish>.</finish>	A DOS screen appears and the cpf file is parsed.
			The following line appears:
			Press any key to continue.
9.	•	<ul> <li>Press any key to continue.</li> </ul>	The following window appears:
			InstallShield Self-extracting EXE
			Do you wish to continue?

No.	Procedure Steps	Display / Comment
10.	• Click <yes></yes>	Files are extracted.
		Then the following window appears:
		Welcome
11.	Click <next>.</next>	The following window appears:
		Software License Agreement
12.	Click <yes>.</yes>	With WINDOWS 95: if asked to install WINSOCK2, answer <no>.</no>
		The following window appears:
		Select Components
13.	• Check that both components <pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	The following window may appear: Question
14.	Click <yes> to overwrite the contents</yes>	The following window appears:
	of this directory.	Start copying files
15.	Click <next>.</next>	The following window appears:
		Setup
		Files are copied.
		Then the following window appears:
		Setup complete
16.	• Click <finish>.</finish>	Setup is complete
17.	Eject the CD ROM.	Software installation is finished.
18.	Double-click the PRID – icon on the desktop to start the PRID application.	The first time PRID 1.1.10 starts, the site info screen appears.
19.	<ul> <li>Please fill it in. This window will not appear any more.</li> <li>Make sure that the ID – tablet is switched on</li> </ul>	The window Please enter username/password appears
20.	<ul> <li>Enter username and password</li> </ul>	PRID application starts up.

## 3 Further Steps for Start up

This chapter describes the following installation steps:

- Install and select the language file
- Install the configuration file adc.cpf.
- Adaptation of IP\_address and subnet mask.

## 3.1 Install and select the Language File

#### **Installation Procedure**

No.	Pr	ocedure Steps	Display / Comment
1.	•	Start the PRID application if not already running	
2.	•	Insert the floppy disk with the language files.	
3.		Select from the menu bar Configuration Change User	Window Enter username and password appears
4.	•	Change username to service, enter password and hit <return></return>	
5.		Select Configuration Service Install languages	The window select language*SET file appears
6.	•	Choose the source of the language files (floppy drive).	
7.	•	Click <open>.</open>	All language files are loaded
8.		Select Configuration System Manager Change language	
9.	•	Choose the customer specific language and click <save>.</save>	
10.	•	To make the language active restart the application.	

## 3.2 Install the Configuration File adc.cpf



The cpf-file with the site specific network addresses incorporated must have been created in advance.

Changing of the cpf-file is only necessary if you integrate into an existing network. With a pure ADC network the default cpf-file (SHIPMENT.CPF) can be used and this installation step 3.2 can be skipped.

No.	Procedure Steps	Display / Comment
1.	<ul> <li>Start the PRID application if not already running</li> </ul>	
2.	<ul> <li>Insert the floppy disk with the adc.cpf file.</li> </ul>	
3.	Select from the menu bar Configuration Change User	Window Enter username and password appears
4.	<ul> <li>Change username to service, enter password and hit <return></return></li> </ul>	
5.	• Click Configuration Service load cpf.file	ADC CPF-file window appears
6.	• Click Load/Parse	The window Load CPF-file appears
7.	<ul> <li>choose the source of the adc.cpf file (floppy drive) and click <open></open></li> </ul>	A DOS window appears: Press any key to continue
8.	Press any key.	cpf.file is installed.

# 3.3 Adaptation of the Network Settings

No.	Procedure Steps	Display / Comment
1.	Stop the PRID application if running	
2.	Select	
	My computer	
	Control Panel	
	Network	
3.	• Select Protocols TCP/IP	If TCP/IP is not installed, you first have to install it; see section 6.5, DD+DIS 050.99E
	Properties	
4.	Select	
	Specify an IP-address	
5.	<ul> <li>modify ip-address and subnet mask if required and click <ok></ok></li> </ul>	
6.	<ul> <li>shut down the PC and switch it off</li> </ul>	
7.	connect the network cable	
8.	<ul> <li>switch on the PC and start the PRID software</li> </ul>	



To check the function of the ID-Station identify a cassette.